


# The Covington

**COMBINATION PLANTER  
and  
FERTILIZER DISTRIBUTOR**



**Model TP-46**

**COVINGTON PLANTER CO.**

**P.O. BOX 2 ALBANY, GEORGIA 31702**

**(229) 888-2032 FAX (229) 888-0448**

## Instructions for Attaching Covington Model TP-46 Planter to Cultivator Frame

We furnish with the planters two opening shovels 7x10", and four listing points 2½x6". Attach two shovels to your two opening tines, and the four listing points to your four listing tines. Turn the cuffs on the listing tines around so that the plow shanks on which you bolt the listing points will be in front of the tines. The shanks, the opening shovels are on, are to be behind the front ends of the tines.

Remove the pull yokes on the front end of the planter frames and bolt these to the under sides of the front bar of the cultivator frame, setting the centers of the two yokes the distance apart you wish the rows to be; using the two bolts in the yokes and the two outside holes of the yokes. Next bolt the opening tines through the two center holes of the yokes. Next attach the lifting bars to the rear frame of the cultivator. These bars are tied to the planters.

Now run the front ends of the planter frames over these lifting bars and reconnect the yokes you have just bolted to the front bar of the cultivator frame. Now pull under the presser wheel frame and bolt ends to main planter frame, and under the upright front braces from the fertilizer box; and then bolt the ends of the opening disc bars to the rear ends of the main planter frames.

Next put the four listing tines on each side of the planter so that they will be 10 inches apart from center to center of the points.

Now take the double fertilizer spouts and slip them astride of the opening tines and fasten the lower end against the opening shovels, and the cross bar that is on the upper shovel bolt. Next place seed spout in the clamp just above the opening disc and attach upper end of spout, under the cotton seed can, with flat head bolt, which goes through main bottom. Now you have the planters properly set up and mounted, and ready for a tryout and adjustments.

### HOW TO MAKE ADJUSTMENTS

If you want to plant below a level, let the opening shovel shank down and set plow more on its points, and then set listing points to fill in furrow to suit. If you wish to plant on a level or above the level, set opening plow to run shallow, or flat and set the listing tines wider apart and to run deeper, or use longer points or plows to raise list to height you wish.

You regulate the depth of covering by making adjustments up and down the slots in the frame holding the disc openers. The covering is done by the presser-drive wheels, and there will be no dragging or choking.

### HOW TO PLANT WITHOUT BEDDING

If you don't bed your land before planting, you can plant and bed all at the same time. To do this you use the tine with the rolling coulter on it, but turn this tine around so that you can open a furrow for the rolling coulter to move in. This will let the rolling coulter into the subsoil. Set on the cultivator frame, two center-furrowing tines for plowing out the other two middles. Be sure to use plows large enough to break all the topsoil to destroy the little grass and weeds.

This method of planting is almost universally used in this section. It has many points of advantage over bedding, provided the soil is not of a wet nature. If you want 3-foot rows, set the tractor wheels 6 feet apart, bolt front and rear and middle breaking tines 3 feet apart, and let inside tractor wheels follow the last furrow and the tractor be-

comes your row marker.

Your tractor will work this way better on hill-side land where there are curved rows, and then you save the cost of bedding.

### MAKE ALL ROWS THREE FEET

A row 3 feet wide is about right for all crops, such as cotton, corn, peanuts, peas, beans, etc. By adopting a standard width row, you do not have to buy so many sizes of plows, and you have less adjusting to make with your cultivator and tractor.

### FERTILIZER IN TWO STREAMS

As the fertilizer is distributed the flow is split in two streams about five inches apart, and the seeds are always planted exactly in the center of these two streams. As the seeds are not in contact with the fertilizer there will be no risk of damaging or killing the seed before they germinate, and further, as there is no fertilizer directly under the seed there will be no injury to the tap roots of the plants. You get better stands. Your plants will be more vigorous and will grow off faster, enabling you to give the plants quicker and better cultivation at the first operation and thereby helping to better destroy the first weeds and grass, and save you most or all of the expensive hoe work later on. The U. S. Dept. of Agriculture claims that the yields of all crops will be largely increased by so dividing the fertilizer into two streams as is done by all our present types of planters, both horse and tractor drawn.

### HOW TO ADJUST THE FLOW OF FERTILIZER

Set the bolt that the upper end of the knocker's arm rests against, so that the vibrator pan will move back about 3/16 or ¼ of an inch. This will be enough motion to make the fertilizer work its way over the pan, and then adjust the gate at front end of pan up or down to give the amount you wish per acre.

### HOW TO REGULATE COTTON SEED TO HILL

This is regulated by the depth the fingers reach into the seed can. The seed conveyor or adjuster is attached to the bottom of the seed hopper by a stove bolt, the head of which is seen in the bottom of the can. Loosen this bolt with a screw driver and adjust the conveyor in or out to regulate the number of seed in hill. Set dropping fingers all the same length and so that they will just miss the back wall of the seed conveyor. Whenever the conveyor is moved, reset fingers accordingly.

### HOW TO PUT ON THE GRAIN ATTACHMENT

Remove the cotton seed dropping shaft as a whole by taking out the four stove bolts holding the bearings to the main frame; then set on the grain attachments and bolt back with the same bolts, and through the same holes at the end of the frame. Tie the grain attachment can to the main cotton seed can by bolting the bracket that is on the grain attachment through the hole which is about five or six inches from the bottom of the cotton seed can. Put in the grain attachment whatever kind of plates you wish to use, adjusting this plate in the grain attachment so that the plate will turn freely under the plate washer. This adjustment is made by a cone similar to the adjustment made in bicycle or automobile wheels. You can turn the cone down tight and lock the plate, causing the wheel to drag, so be careful that the adjustment is made so that loose motion in the plate is removed, but still left loose enough to turn freely.

### DIFFERENT PLATES WILL PLANT DIFFERENT KINDS OF SEED

The plates we furnish, known as the corn plates can be used for planting all kinds of small seed such as sorghum, etc.—just as perfectly as if the plates were made for these particular seeds. The peanut plates that we furnish can also be used for planting such seed as peas, beans, and other round seeds that are too large to be planted with corn plates. Chemically delinted cotton seed can be planted perfectly with the large peanut plate; peas and beans can also be planted with the same plate.

For planting snap beans, it is best to plant these with a special plate made to work inside the cotton seeds hopper. We have this plate and can furnish it on special orders.

### DRILLING ATTACHMENT FOR VERY SMALL SEED

We make an attachment to be used in the regular cotton seed can for drilling very small seeds such as cabbage, turnips, collards, etc. When this attachment is wanted, we can furnish it, and will send along with it directions on how to use. This attachment will drill small seed as perfectly as can be done with any regular garden drilling planter.

### HOW TO PLANT BEANS AND CORN AT THE SAME TIME

If you wish to plant velvet beans, soy beans, peas,

etc., with corn, you plant the corn out of the grain attachment and the other seed out of the regular cotton seed can, and to do this, first remove the cotton stirrer or agitator from the cotton seed hopper.

Next remove the cotton seed conveyor from the bottom of the seed hopper, so as to make the hole large enough for the beans to pass out. This conveyor is held in bottom by a flat head stove bolt, which is reached by a screw driver through the main hopper.

Then put the bean plate in bottom and fasten same as was the seed stirrer and fasten the cut-off brush over plate and through the cotton seed slot in the rear of big can. Put the bean plate and brush in position before you bolt grain attachment in hole just above the cottonseed slot. We furnish a four hole bean plate. If you wish only two holes plug the other two holes. You can make this plate plant the distance you wish by changing the size of the sprocket.

### USE OF SPROCKETS EXPLAINED

You will notice in all the tables of distances that the sprockets work in pairs, for example: "12x6." Each figure represents the number of teeth on the sprocket, and the first figure, or sprocket, is always the driving or pulling sprocket, and the second figure is the driven or pulled sprocket. So don't forget this.

## REPAIR PARTS FOR MODEL TP-46 TRACTOR DRAWN PLANTERS

33	Steel Sprocket Chain, Per Ft. ....	TP518	Disc Bearing Kit Consists of
C 94	Plate Brush, each .....		TP517 (2) and TP49B (1963- ) .....
C802	Cotton Seed Conveyor, each .....	TP507	4-Hole Velvet Bean Plate, each .....
C804	10-Tooth Pinion Gear, each .....	TP508	6-Hole Delinted Cottonseed Plate, ea.
C809A	Steel Finger Plate, Complete With Four Fingers, each .....	TP509	36-Hole Snap Bean Plate, ea. ....
C809	Steel Plate, each .....	C828	8-Hole Sorghum Plate, ea. ....
C811	Dropping Fingers, each .....	C867	48-Hole Soybean Plate, ea. ....
C817	6-Tooth Sprocket, each .....	C870	Blank Plate, ea. ....
C818	8-Tooth Sprocket, each .....		<b>PLANTER STEEL PARTS</b>
C819	10-Tooth Sprocket, each .....	TP 35R	Main Angle Frame 33 $\frac{3}{4}$ " Right, ea. ....
C845	Presser Wheel, One Half, each .....	TP 35L	Main Angle Frame 33 $\frac{3}{4}$ " Left, ea. ....
C853	Cotton Seed Stirrer, each .....	TP 36	Main Seed Can (Round) each .....
C857	Main Can Ring, each .....	TP 36A	Cover for Main Seed Can, each .....
C864	6-Tooth Idler Sprocket, each .....	TP 37	Seed Agitator for Main Seed Can, ea.
C864B	Pipe Spacer, $\frac{1}{2}$ x 1- $\frac{1}{8}$ ", for Idler, ea. ....	TP 38	Stirring Shaft only, 7/16x10 $\frac{3}{8}$ ", each ..
TP 1	Dropping & Stirring Shaft Brg., ea. ....	TP 39	Stirring Shaft Complete with Pipe Space Bushing, each .....
TP 7	12-Tooth Sprocket, each .....	TP 40	Stirring Shaft, Complete with TP1, TP2, TP7, TP502 and TP32, each .....
TP 14	Presser Wheel Shaft Bearing, each .....	TP 41	Pipe Space Bushing, for Stirring Shaft, Size $\frac{1}{2}$ x1-15/16", each .....
TP 19	12" Opening Disc, each .....	TP 42	Pipe Space Bushing for Stirring Shaft, Size $\frac{1}{2}$ x5 $\frac{3}{8}$ ", each .....
TP 19A	12" Opening Disc, Complete with TP503, and TP49A, (Before 1963), ea. ....	TP 43	Dropping Shaft only, (7/16x10"), ea. ....
TP 30	Presser Wheel Shaft, S. E., each .....	TP 44	Dropping Shaft Complete with C809, C811, C818, TP1, TP32 and $\frac{1}{2}$ " Pipe Space Bushings .....
TP 31	Presser Wheel Shaft, Plain End, ea. ....	TP 45	Dropping Shaft Complete with all Pipe Space Bushings, each .....
TP 32	Sprocket Bushing, each .....	TP 46	Dropping Shaft Pipe Space Bushings, $\frac{1}{2}$ x3 $\frac{3}{8}$ ", each .....
TP 33	Pull Yoke Bearing, each .....	TP 47	Dropping Shaft Pipe Space Bushings, $\frac{1}{2}$ x4-1/16", each .....
TP495	Vegetable Drilling Attachment, pair .....	TP 48	Square Hole Washer (1 $\frac{1}{8}$ x15/32") for Stirring and Dropping Shaft, ea. ....
TP500	Main Hopper Bottom, each .....		
TP500A	Main Hopper Bottom, Complete with C853, C802, TP501 & seed agitator, ea. ....		
TP501	18-Tooth Plate Gear, each .....		
TP502	Pinion Gear, each .....		
TP503	Disc Bearing (Before 1963) .....		
TP504	Disc Bearing Spacer (Before 1963) .....		
TP513	Disc Bearing (1963- ) .....		
TP514	Disc Bearing Spacer (1963- ) .....		
TP515	Disc Bearing End Cap (1963- ) .....		
TP516	Pipe Bushing for TP513, $\frac{3}{4}$ x3 $\frac{1}{8}$ " (1963- ) .....		
TP517	Disc Bearing Unit (Consists of TP513, TP514, TP515, TP516 (1963- ) .....		

TP 49A Pipe Bushing for TP503 Disc Bearing, Size  $\frac{3}{4} \times 3\frac{1}{4}$ ", (Before 1963).....

TP 49B  $9/16 \times 10$ " Sq. Steel Axle for Disc Bearing, each .....

TP 50 Opening Disc Braces, Pair of 2.....

TP 51  $\frac{3}{8} \times 9\frac{1}{4}$ " Carriage Bolt with  $\frac{3}{8} \times 8$ " Pipe Space Bushing for Opening Disc.....

TP 51A  $\frac{3}{8} \times 9\frac{1}{4}$ " Carriage Bolt for Opening Disc; each .....

TP51B  $\frac{3}{8} \times 8$ " Pipe Space Bushing for Opening Disc, each .....

TP 52 Seed Spout Main Support complete with  $\frac{3}{8} \times 8\frac{1}{2}$ " Carriage Bolt & Pipe Bushing and TP619 (2), each.....

TP 52A  $\frac{3}{8} \times 8\frac{1}{2}$ " Carriage Bolt for Seed Spout Support, each.....

TP 52B Pipe Space Bushing for Seed Spout Support,  $\frac{3}{8} \times 2\frac{1}{2}$ ", pair .....

TP 52C Pipe Space Bushing for Seed Spout Support,  $\frac{3}{8} \times 1\frac{1}{2}$ ", each .....

TP 53 Pipe Bushing for Support of Stirring Shaft, Size,  $\frac{1}{4} \times 1-7/16$ ", each.....

TP 54 Presser Wheel Scrape Complete, ea.....

TP 55 Presser Wheel Scrape, each.....

TP 56 Presser Wheel Scrape Braces, Pr. of 2.....

TP 57 Presser Wheel Pipe Space Bushing  $\frac{1}{4} \times 1\frac{3}{4}$ ", each .....

TP 58 Presser Wheel Assembly with Opening Disc Complete, each.....

TP 59 Presser Wheel Pull Arm, each.....

TP 60 Rear Lift Yoke, Complete, ea.....

TP 60A Rear Lift Yoke Bracket, each.....

TP 60B Rear Lift Yoke Pipe Space Bushing, ea.....

TP 60C  $7/16 \times 5$ " Carriage Bolt for Rear Lift Yoke, each .....

TP 62 Steel Washer  $1\frac{1}{2} \times 13/32$ " for TP31 Shaft, each .....

TP 63 Steel Plate Washer,  $2 \times 13/32$ ", ea.....

TP 64 Grease Fitting,  $\frac{1}{8}$ " Pipe Thread, ea.....

TP 65 Can Rod for Main Can & Grain Attachment  $\frac{1}{4} \times 12\frac{1}{2}$ ", each.....

TP 66 Seed Spout (Main), each.....

TP 69 Opening Shovel ( $7 \times 10$ " ), each.....

TP 70 Opening Shovel ( $7 \times 10$ " ) complete with Bolts and Brackets.....

TP 70A Fertilizer Spout Yoke, each.....

TP 70B Fertilizer Spout Yoke Pipe Spacer.....

BC 42 Bolt for Opening Shovel,  $7/16 \times 3$ " Carriage, each .....

TP 72 Bolt for Opening Shovel,  $7/16 \times 1\frac{1}{2}$ " Carriage, each .....

TP 73 Cultivator Point ( $2\frac{1}{2} \times 6$ " ), each.....

TP 74 Cult. Point ( $2\frac{1}{2} \times 6$ " ), Comp. with Bolts, each .....

TP 75 Bolt for Cult. Point  $7/16 \times 1\frac{3}{4}$ ", each.....

TP120 Yoke, Frame Spacer, ea.....

TP149 Idler Bracket (Long Slotted Offset) for C864 .....

TP150 Idler Complete (w/TP 149).....

TP151 Idler Complete (w/TP 745).....

TP619 Seed Spout (Main) Support Bracket.....

TP691 Front Pull Yoke, Spec. for 3" Pittsburgh Cult. Frame.....

TP692 Opening Disc Assy. Comp w/ TP513, TP514, End Cap, Bushing and Brace (1963- ).....

TP745 Idler Bracket (Short Slotted Offset) for C864 .....

#### DISTRIBUTOR PARTS

TP 2 Drive Vibrator, each.....

TP 34 Vibrating Pan Bushing, each.....

TP 77 Fertilizer Spout, each.....

TP 78 No. 2 Vibrator Spring, each.....

TP 79 Vibrating Pan Complete with Yoke,\* No. 2 Vibrator Spring, Pipe Bushing and Bolt, each .....

TP 79A Vibrating Pan (Riveted Assembly).....

TP 80 Vibrating Pan Yoke, each.....

TP 81 Vibrating Pan Bushing,  $\frac{1}{4} \times 3$ " Pipe, each .....

TP 81A  $5/16 \times 3\frac{3}{4}$ " Carriage Bolt for Vibrating Pan Yoke, each .....

TP 82 Vibrating Arm with Bolt, each.....

TP 82A Vibrating Arm only, each.....

TP 83A Fertilizer Box, each.....

TP 84A  $\frac{3}{8} \times \frac{3}{4}$ " Machine Bolt with Wing Nut for Fertilizer Box Cut-off Gate, each.....

TP 84B Fertilizer Box, with Cut-off Gate, each.....

TP 85 Fertilizer Box Cut-off Gate, each.....

TP86FA Fertilizer Box End (Metal) Front.....

TP86RA Fertilizer Box End (Metal) Rear.....

TP 87 Front Fertilizer Box Brace, each.....

TP 87A Box Steady Brace, each.....

TP 88 Rear Fertilizer Box Brace, each.....

#### SINGLE GRAIN ATTACHMENT PARTS

C900 Grain Attachment, Bottom, each.....

C900A Grain Attachment, Bottom Complete with C901, C908, TP910, ea.....

C901 16-Tooth Plate Gear, ea.....

C908 Adjustment Cone, ea.....

TP910 Plate Washer for Grain Attachment, each .....

TP 61A Stud Bolt (for G. A. Bottom),  $\frac{3}{8} \times 1\frac{3}{4}$ " Cge. with Sq. Nut, ea.....

TP 89 Grain Attachment Shaft, only,  $7/16 \times 10$ ", ea.....

TP 90 Grain Attachment Shaft, Complete with Pipe Space Bushings.....

TP 91 Grain Attachment Shaft, Complete with C804, C818, TP1 and TP32, ea.....

TP 91A Pipe Space Bushing, Size  $\frac{1}{2} \times 5-5/16$ " for Grain Attachment Shaft, ea.....

TP 91B Pipe Space Bushing, Size  $\frac{1}{2} \times 2\frac{1}{2}$ " for Grain Attachment Shaft, ea.....

TP 93 Grain Attachment Bracket Holder, each .....

TP 94 Grain Attachment Seed Can, ea.....

TP702 Adjusting Gate (for G. A. Can), ea.....

TP 95 Grain Attachment Seed Spout, ea.....

TP 96 Grain Attachment, Complete with Plates.....

TP 97 Tilt Bracket Anchor (Sing. G. A.).....

C904 4 Cell Corn Plate, ea.....

C905 8 Cell Peanut Plate, ea.....

C906 16 Cell Peanut Plate (Spanish), ea.....

C907 6 Cell Corn Plate, ea.....

TP525 10 Cell Hybrid Corn Plate, Med. Flat.....

TP527 10 Cell Hybrid Corn Plate, Small Rd.....

TP528 10 Cell Hybrid Corn Plate, Med. Rd.....

TP529 10 Cell Hybrid Corn Plate, Lge. Rd.....

TP530 16 Cell Soy Bean Plate.....

TP531 16 Cell Popcorn or Sorghum Plate.....

TP532 16 Cell Peanut Plate (Large).....

TP533 20 Cell Delinted Cottonseed Plate.....

TP534 10 Cell Corn Plate, Small, Single Cross Hybrid, each.....

TP537 16 Cell Peanut Plate, Jumbo Seeded Florigiant, each .....

TP538 10 Cell Hybrid Corn Plate, Large Flat, each .....

TP539 28 Cell Peanut Plate, Small Seeded Spanish, each .....

TP540 2 Cell Velvet Bean or Watermelon Plate, ea.....

TP548 37 Cell Soy Bean Plate, ea.....

TP550 Sunflower Plate, ea.....

#### RUBBER TIRE

TP649 Rubber Tire (for Press Wheel), ea.....